How to install the bearings into the rear upper wishbones

Uninstall process

STEP 1

Remove the dust caps or whatever is left of it.

STEP 2

Place large ring of the supplied tool set on the press with the grooved side facing upwards

STEP 3

Place wishbones on this side of the tool. It should slide perfectly into the slight groove

STEP 4

Place the short pipe properly on the old bearing

STEP 5

Installation of the new bearing

STEP 1
Make sure to have removed the rubber dust caps on both ends of the new bearing.

STEP 2
Place the wishbone on the support ring

STEP 3
Place the new bearing on top of the wishbone.

STEP 4

Put the tool on top making sure it sits perfectly on the new bearing.

STEP 5

Press in the new bearing until it won’t go in any further. At that point it sits exactly in the middle of the wishbone.

STEP 6
Mount the rubber dust caps on both sides of the bearing.